

- Remove all loose dirt/detritus from the paving
- Pack the perimeter joints of the area to be treated to prevent material from 'running away'
- Pre-soak the paving (removing any ponded water)
- Mix the material as per our recommendations
- Apply the material to the pre-soaked paving using a squeegee
- Work the material back and forth over the joints to ensure any settlement is filled
- Keeping the remaining surface mortar moist, wait for the joint to reach initial set (firm to the touch)
- Wash surface mortar off using a squeegee, soft broom or similar (a squeegee generally leaves the fullest joint) and copious amounts of water ensure no material is left on the surface
- Ponded water should be removed with a sponge or similar
- Leave to fully cure
- Clean if necessary using a hose/water and then open to traffic when ready



The above points are intended as a practical guide only; should you have any queries regarding any of the points herein, please do not hestitate to contact us.

01827 871 871

ultrascape@instarmac.co.uk

